

FCSL550 - INSTALLATION INSTRUCTIONS

CAUTION: BEFORE CONNECTING THE FIXTURE TO A POWER SUPPLY, MAKE SURE THE POWER IS SWITCHED OFF.



DETAILED ILLUSTRATION

GENERAL:

1. Before starting the installation, make sure all electricity has been turned off and electrical breaker has been locked out and tagged out.
2. To ensure the success of the installation, be sure to read these instructions and review the diagrams thoroughly before beginning.
3. All electrical connections must be in accordance with local codes, ordinances, or the National Electrical Code.

NOTE: The important safeguards and instructions appearing in this manual are not meant to cover all possible conditions and situations that may occur.

INSTALLATION INSTRUCTIONS:

- 1) Remove the four (4) screws holding the lens and face.
- 2) Remove internal components.
- 3) **FOR DRYWALL:** Cut opening in wall for mounting. Opening should be $5\frac{5}{16}$ " x $3\frac{3}{16}$ ".

NOTE: Drywall install includes (2) screw holes in the back of the Inner Housing to tighten the fixture in place using the Drywall Wing (DWR). PVC Housing not needed. Also, mount the Inner Housing with back of flange flush with drywall surface.

- 4) **FOR CONCRETE POUR:** Level and stabilize fixture. Insert back box in form with lip edge of back box against outside of mounting surface. If provided back box-less electrical assembly, be sure to cover holes on back of fixture housing to prevent leakage. The hole is used to mount ballast to fixture.
- 5) Connect power through rear hole.
- 6) Once mounting is complete, connect the green ground wire to provide ground to the fixture.
- 7) Replace ballast cover, secure ballast tray and install approved lamp or LED provided.
- 8) Attach lens and frame, replace four (4) screws and tighten evenly.
- 9) Restore power and test fixture. If fixture does not turn on, disconnect power before checking for problems.

NOTE: Fixtures are listed for installation with liquid tight or rigid wall conduit only. Fixtures installed without a silicone bead will void the warranty.

IMPORTANT: All FC|SSL products can be cleaned with non-abrasive and chemical free agents. Use a soft cloth with mild detergent on exterior only.



Light Pattern

