FCW3700 Series - INSTALLATION INSTRUCTIONS

CAUTION: BEFORE CONNECTING THE FIXTURE TO A POWER SUPPLY, MAKE SURE THE POWER IS SWITCHED OFF.

Including: W3707, W3710, W3712, W3707p, W3710p, W3712p

DETAILED ILLUSTRATION



GENERAL:

- Before starting the installation, make sure all electricity has been turned off and electrical breaker has been locked out and tagged out.
- To ensure the success of the installation, be sure to read these instructions and review the diagrams thoroughly before beginning.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electrical Code.
- These fixtures are intended to be mounted to a Octagonal Box directly supported by the building structure.

NOTE: The important safeguards and instructions appearing in this manual are not meant to cover all possible conditions and situations that may occur.

INSTALLATION:


- 1. Make wiring connections inside the octagonal box (FIG. 1).
- 2. Loosen set screws to Mounting Bracket. **NOTE:** Do not remove screws.
- 3. Feed wires from octagonal box through Mounting Bracket.
- Level mounting bracket. Install to octagonal box using flat headed screws (screws provided by others). (FIG. 2)

IMPORTANT: Do not deform bracket when tightening.

- 5. Position fixture onto mounting bracket.
- 6. Tighten set screws to hold fixture flush to wall. (FIG. 3)
- 8. Installer MUST add a bead of silicone where the edge of the Fixture meets the Mounting Surface.

NOTE: Fixtures are listed for installation with liquid tight or rigid wall conduit only. Fixtures installed without a silicone bead will void the warranty.

OPTIONAL: Mounting Bracket can be removed from backplate to add additional mounting screws.



J0 Rev. 0217